

NOTES:

- 1 APPLY ONE DOT OF LOCTITE 222MS THREADLOCKER ON FEMALE THREADS OF PUSH BUTTON. SEE 5874 SERIES OPERATION AND MAINTENANCE MANUAL FOR PROPER APPLICATION PROCEDURE.
- 2 | 5874PB INCLUDES VRK5874 CARTRIDGE ASSEMBLY (NOT SHOWN) AND PBA7 PUSHBUTTON.
- 3 REFER TO 5874 SERIES/VRK5874 OPERATION AND MAINTENANCE MANUAL FOR INSTALLATION INSTRUCTIONS.
- 4. FOR TUBING ROUTING AND LENGTHS SEE SHEET 2 OF INSTALLATION DRAWING.





PARTS BREAKDOWN



1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (775) 359-7424 E-MAIL: HAWS@HAWSCO.COM

WEBSITE: WWW.HAWSCO.COM MODEL(S)

0002076860

WHEN ORDERING PARTS PLEASE SPECIFY MODEL NUMBER.

THREE-BUBBLER FOUNTAIN